ConnectX®-3 Pro 40Gb/s Ethernet Single and Dual QSFP+ Port Network Interface Card User Manual for Open Compute Project

P/N:

MCX345A-BCPN, MCX346A-BCPN, MCX345A-BCQN, MCX346A-BCQN

Rev 1.2

www.mellanox.com

NOTE:
THIS HARDWARE, SOFTWARE OR TEST SUITE PRODUCT (“PRODUCT(S)”) AND ITS RELATED DOCUMENTATION ARE PROVIDED BY MELLANOX TECHNOLOGIES “AS-IS” WITH ALL FAULTS OF ANY KIND AND SOLELY FOR THE PURPOSE OF AIDING THE CUSTOMER IN TESTING APPLICATIONS THAT USE THE PRODUCTS IN DESIGNATED SOLUTIONS. THE CUSTOMER'S MANUFACTURING TEST ENVIRONMENT HAS NOT MET THE STANDARDS SET BY MELLANOX TECHNOLOGIES TO FULLY QUALIFY THE PRODUCTO(S) AND/OR THE SYSTEM USING IT. THEREFORE, MELLANOX TECHNOLOGIES CANNOT AND DOES NOT GUARANTEE OR WARRANT THAT THE PRODUCTS WILL OPERATE WITH THE HIGHEST QUALITY. ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT ARE DISCLAIMED. IN NO EVENT SHALL MELLANOX BE LIABLE TO CUSTOMER OR ANY THIRD PARTIES FOR ANY DIRECT, INDIRECT, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES OF ANY KIND (INCLUDING, BUT NOT LIMITED TO, PAYMENT FOR PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY FROM THE USE OF THE PRODUCT(S) AND RELATED DOCUMENTATION EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Mellanox Technologies
350 Oakmead Parkway Suite 100
Sunnyvale, CA 94085
U.S.A.
www.mellanox.com
Tel: (408) 970-3400
Fax: (408) 970-3403

© Copyright 2015. Mellanox Technologies. All Rights Reserved.

Mellanox®, Mellanox logo, BridgeX®, ConnectX®, Connect-IB®, CoolBox®, CORE-Direct®, InfiniBridge®, InfiniHost®, InfiniScale®, MetroX®, MLNX-OS®, TestX®, PhyX®, ScalableHPC®, SwitchX®, UFM®, Virtual Protocol Interconnect® and Voltaire® are registered trademarks of Mellanox Technologies, Ltd.

ExtendX™, FabricIT™, HPC-X™, Mellanox Open Ethernet™, Mellanox PeerDirect ™, Mellanox Virtual Modular Switch™, MetroDX™, Unbreakable-Link™ are trademarks of Mellanox Technologies, Ltd.

All other trademarks are property of their respective owners.

Table of Contents

Table of Contents 3
List of Figures 5
List of Tables 6
Revision History 7
About this Manual 8
Chapter 1 Introduction 10
1.1 Product Overview 10
1.2 Features and Benefits 11
1.3 Operating Systems/Distributions 11
1.4 Connectivity 12
Chapter 2 Interfaces 13
2.1 Ethernet Interface 13
2.2 PCI Express Interface 13
2.3 I2C-compatible Interface 13
2.4 LED Interface 13
2.5 Network Controller Sideband Interface (NC-SI) 14
Chapter 3 Hardware Installation 15
3.1 System Requirements 15
3.1.1 Hardware 15
3.1.2 Operating Systems/Distributions 15
3.1.3 Software Stacks 15
3.2 Safety Precautions 15
3.3 Pre-installation Checklist 15
3.4 Card Installation Instructions 15
3.5 Cables and Modules 15
3.6 Identify the Card in Your System 16
3.6.1 On Windows 16
3.6.2 On Linux 17
Chapter 4 Driver Installation 18
4.1 Linux Driver 18
4.1.1 Hardware and Software Requirements 18
4.1.2 Installing the Driver 18
4.1.3 Loading the Driver 19
4.1.4 Unloading the Driver 19
4.1.5 Uninstalling the Driver 19
4.2 Windows Driver 19
4.2.1 Hardware and Software Requirements 20
4.2.2 Downloading MLNX_WinOF 20
4.2.3 Extracting Files Without Running Installation 20
4.2.4 Installing MLNX_WinOF 22
4.2.4.1 Attended Installation 23
4.2.4.2 Unattended Installation 28
4.2.5 Upgrading MLNX_WinOF 29
4.2.6 Installation Results 29
4.2.7 OpenSM Activation 30
4.2.8 Uninstalling MLNX_WinOF 31
4.2.8.1 Attended Uninstall 31
4.2.8.2 Unattended Uninstall 31

Mellanox Technologies Confidential

4.2.9 Assigning Port IP After Installation 31
4.3 VMware Driver 32
4.3.1 Installing and Running the VBI Driver on ESXi-5.x 33
4.3.2 Installing and Running the offline_bundle Driver on ESXi-5.x 33
4.3.3 Removing the VIB/offline_bundle Driver 34
4.4 FlexBoot 34
Chapter 5 Updating Card Firmware 35
Chapter 6 Troubleshooting 37
6.1 General. 37
6.2 Linux 38
6.3 Windows 39
Chapter 7 Specifications 40
7.1 MCX345A-BC[P/Q]N Specifications 40
7.2 MCX346A-BC[P/Q]N Specifications 41
7.3 Board Mechanical Drawing and Dimensions 42
7.4 Adapter LED Operation 43
7.5 Regulatory Statements 43
Appendix A Finding the MAC/GUID and Serial Number on the Card 44
A.1 Retrieving Card GUID. 45
Appendix B Interface Connectors Pinout 47
B.1 PCI Express x8 Connector Pinout 47
B.2 I2C-compatible Connector Pinout 48
B.3 NC-SI Interface Pinout 48
Appendix C Safety Warnings 49
Appendix D Avertissements de sécurité d'installation (Warnings in French) 51
Appendix E Sicherheitshinweise (Warnings in German) 53
Appendix F Advertencias de seguridad para la instalación (Warnings in Spanish) 55

Mellanox Technologies Confidential

List of Figures

Figure 1: I2C Harness 13
Figure 2: PCI Device. 16
Figure 3: Support Download Assistant 36
Figure 4: Mechanical Drawing of the Network Interface Card 42
Figure 5: MCX345A-BCPN Board Label (Example only - see *Note*) 44
Figure 6: MCX345A-BCQN Board Label (Example only - see *Note*). 44
Figure 7: MCX346A-BCPN Board Label (Example only - see *Note*) 45
Figure 8: MCX346A-BCQN Board Label (Example only - see *Note*). 45
Figure 9: PCIe Connector Pinout 47
Figure 10: Compatible Connector Plug and Pinout 48
Figure 11: NC-SI Interface Pinout 48

Mellanox Technologies Confidential

List of Tables

Table 1: Revision History Table 7
Table 2: Documents List 8
Table 3: Single and Dual-port 40 Gigabit Ethernet Network Interface Cards. 10
Table 4: Features 11
Table 5: Software and Hardware Requirements 18
Table 6: Software and Hardware Requirements 20
Table 7: MCX345A-BC[P/Q]N Specifications Table 40
Table 8: MCX346A-BC[P/Q]N Specifications Table 41
Table 9: Physical and Logical Link Indication 43
Table 10: I2C-compatible Connector Pinout 48

Mellanox Technologies Confidential

Revision History

This document was printed on February 4, 2015.

Table 1 - Revision History Table

Date	Rev	Comments/Changes
February 2015	1.2	• Updated document to indicate card respin to comply with OCP spec 2.0 • Updated Flash part number to W25Q32FVSSIG • Changed description of I2C interface. See Section 2.3, "I2C-compatible Interface," on page 13 and Appendix B.2, "I2C-compatible Connector Pinout," on page 48. • Updated voltage to 5VAUX and 3.3VAUX. See Section 7.1, "MCX345A-BC[P/Q]N Specifications," on page 40 and. Section 7.2, "MCX346A-BC[P/Q]N Specifications," on page 41 • Updated LED functionality. See Section 7.4, "Adapter LED Operation," on page 43. • Added board labels. See Appendix A, "Finding the MAC/GUID and Serial Number on the Card," on page 44.
July 2014	1.1	• Updated note on air flow. See Section 7.1, "MCX345A-BC[P/Q]N Specifications," on page 40 and Section 7.2, "MCX346A-BC[P/Q]N Specifications," on page 41. • Added Appendix B.3, "NC-SI Interface Pinout," on page 48
October 2014	1.0	First Release

Mellanox Technologies Confidential

About this Manual

This *User Manual* describes Mellanox Technologies ConnectX®-3 Pro 40 Gigabit Ethernet Single and Dual QSFP+ Port PCI Express x8 network interface cards. It provides details as to the interfaces of the board, specifications, required software and firmware for operating the board, and relevant documentation.

Intended Audience

This manual is intended for the installer and user of these cards.

The manual assumes basic familiarity with Ethernet networks and architecture specifications.

Related Documentation

Table 2 - Documents List

Mellanox Firmware Tools (MFT) User Manual Document no. 2204UG	User Manual describing the set of MFT firmware management tools for a single node. See http://www.mellanox.com => Products => Software => Firmware Tools
MLNX_EN for Linux README Driver Kit for Mellanox Adapter Cards with 10GigE Support Document no. 2950	This document provides information on the MLNX_EN Linux driver and instructions for installing the driver on Mellanox ConnectX adapter cards supporting 10Gb/s Ethernet.
Mellanox OFED for Linux User Manual Document no. 2877	User Manual describing OFED features, performance, InfiniBand diagnostic, tools content and configuration.See http://www.mellanox.com => Products => Software => Linux SW/Drivers => Mellanox OpenFabrics Enterprise Distribution for Linux (MLNX_OFED)
WinOF VPI for Windows User Manual Document no. 3280	User Manual describing WinOF features, performance, InfiniBand diagnostic, tools content and configuration. See http://www.mellanox.com => Products => Software => Windows SW/Drivers => Mellanox OFED for Windows (WinOF)
Mellanox MLX4_EN Driver for VMware README Document no. 3527	User Manual describing MLX4_EN driver for VMware features, performance, diagnostic, tools content and configuration. See http://www.mellanox.com => Products => Software => Ethernet Drivers => VMware Drivers
IEEE Std 802.3 Specification	This is the IEEE Ethernet specification http://standards.ieee.org/getieee802
PCI Express 3.0 Specifications	Industry Standard PCI Express 3.0 Base and Card Electromechanical Specifications

Mellanox Technologies Confidential

Online Resources

- Mellanox Technologies web pages: http://www.mellanox.com
- Mellanox Technologies Firmware download web page: http://www.mellanox.com => Support => Download Center

Document Conventions

When discussing memory sizes, MB and MBytes are used in this document to mean size in mega bytes. The use of Mb or Mbits (small b) indicates size in mega bits.

Technical Support

Customers who purchased Mellanox products directly from Mellanox are invited to contact us through the following methods.

- URL: http://www.mellanox.com => Support
- E-mail: support@mellanox.com
- Tel: +1.408.916.0055

Customers who purchased Mellanox M-1 Global Support Services, please see your contract for details regarding Technical Support.

Customers who purchased Mellanox products through a Mellanox approved reseller should first seek assistance through their reseller.

Firmware and Software Updates

The Mellanox support downloader contains software, firmware and knowledge database information for Mellanox products. Access the data base from the Mellanox Support web page,

http://www.mellanox.com => Support

or use the following link to go directly to the Mellanox Support Download Assistant page,

http://www.mellanox.com/supportdownloader/.

Mellanox Technologies Confidential

1 Introduction

This is the User Guide for Mellanox Technologies Ethernet network interface cards based on the ConnectX®-3 Pro EN integrated circuit device. These card's connectivity provide the highest performing and most flexible interconnect solution for PCI Express Gen3 servers used in Enterprise Data Centers, High-Performance Computing, and Embedded environments

This chapter covers the following topics:

- Section 1.1, "Product Overview," on page 10
- Section 1.2, "Features and Benefits," on page 11
- Section 1.3, "Operating Systems/Distributions," on page 11
- Section 1.4, "Connectivity," on page 12

1.1 Product Overview

The following tables provide the ordering part number, port speed, number of ports, and PCI Express speed.

Table 3 - Single and Dual-port 40 Gigabit Ethernet Network Interface Cards

Ordering Part Number (OPN)	MCX345A-BCPN, MCX345A-BCQN MCX346A-BCPN, MCX346A-BCQN
Data Transmission Rate	40GigE
Number of ports	MCX345A-BCPN: single-port QSFP+ IPMI and NC-SI disabled MCX345A-BCQN: single-port QSFP+ with IPMI and NC-SI support MCX346A-BCPN: dual-port QSFP+ IPMI and NC-SI disabled MCX346A-BCQN: dual-port QSFP+ with IPMI and NC-SI support
PCI Express SERDES Speed	PCIe 3.0 x8 8GT/s
RoHS	R6
Adapter IC Part Number	MT27524A0-FCCR-BE

Mellanox Technologies Confidential

1.2 Features and Benefits

Table 4 - Features

PCI Express (PCIe)	Uses PCIe Gen 3.0 (1.1 and 2.0 compatible) through an x8 edge connector up to 8GT/s
40 Gigabit Ethernet	Mellanox cards comply with the following IEEE 802.3* standards: IEEE Std 802.3-2008 Ethernet IEEE Std 802.3ae 10 Gigabit Ethernet IEEE Std 802.3ba 40 Gigabit Ethernet IEEE Std 802.3ad Link Aggregation and Failover
Memory	PCI Express - stores and accesses InfiniBand and/or Ethernet fabric connection information and packet data SPI - includes one 4MB SPI Flash device (W25Q32FVSSIG device by WINBOND-NUVOTON) EEPROM - accessible through the I^2C-compatible interface. The EEPROM capacity is 4KB.
RDMA over Converged Ethernet (RoCE)	Leveraging Data Center Bridging capabilities, RoCE provides efficient low latency RDMA services over Layer 2 Ethernet.
CPU offload	Adapter functionality enabling reduced CPU overhead allowing more available CPU
Sockets Acceleration	Applications utilizing TCP/UDP/IP transport can achieve industry leading throughput over InfiniBand or 10 or 40GbE. The hardware-based stateless offload engines in ConnectX-3 Pro reduce the CPU overhead of IP packet transport. Sockets acceleration software further increases performance for latency sensitive applications.
Quality of Service (QoS)	Support for port-based Quality of Service enabling various application requirements for latency and SLA
Hardware-based I/O virtualization	ConnectX-3 Pro provides dedicated adapter resources and guaranteed isolation and protection for virtual machines within the server.
Virtualized Overlay Networks	ConnectX-3 Pro effectively addresses the increasing demand for an overlay network, enabling superior performance by introducing advanced NVGRE and VXLAN hardware offload engines that enable the traditional offloads to be performed on the encapsulated traffic. With ConnectX-3 Pro, data center operators can decouple the overlay network layer from the physical NIC performance, thus achieving native performance in the new network architecture.
SR-IOV	ConnectX-3 Pro SR-IOV technology provides dedicated adapter resources and guaranteed isolation and protection for virtual machines (VM) within the server. I/O virtualization with ConnectX-3 Pro gives data center managers better server utilization while reducing cost, power, and cable complexity.

1.3 Operating Systems/Distributions

- Novell SLES, Red Hat Enterprise Linux (RHEL), Fedora, CentOS and other Linux distributions.

Mellanox Technologies Confidential

- Microsoft Windows Server 2008/CCS 2003, HPC Server 2008
- OpenFabrics Enterprise Distribution (OFED)
- OpenFabrics Windows Distribution (WinOF)
- VMware ESX Server 3.5, vSphere 4.0/4.1

1.4 Connectivity

- Interoperable with 10/40GbE switches
- Passive copper cable with ESD protection
- Powered connectors for optical and active cable support
- QSFP to SFP+ connectivity through QSA module
- Passive copper cable with ESD protection

Mellanox Technologies Confidential

2 Interfaces

Each network interface card includes the following interfaces:

- "Ethernet Interface"
- "PCI Express Interface"
- "I2C-compatible Interface"
- "LED Interface"

2.1 Ethernet Interface

The network ports of the ConnectX®-3 Pro network interface cards are compliant with the IEEE 802.3 Ethernet standards listed in Table 4, "Features," on page 11.

2.2 PCI Express Interface

The ConnectX®-3 Pro network interface cards support PCI Express 3.0 (1.1 and 2.0 compatible) through an x8 edge connector. The device can be either a master initiating the PCI Express bus operations or a slave responding to PCI bus operations. The following lists the PCIe interface features:

- PCIe Base 3.0 compliant, 1.1 and 2.0 compatible
- 2.5, 5.0, or 8.0GT/s link rate x8
- Auto-negotiates to x8, x4, x2, or x1
- Support for MSI/MSI-X mechanisms

2.3 I²C-compatible Interface

A three hole footprint for I²C harness is provided as the I2C-compatible interface. See Figure 1.

Figure 1: I²C Harness



2.4 LED Interface

There are two I/O LEDs per port. For LED specifications please refer to Section 7.4, "Adapter LED Operation," on page 43.

Mellanox Technologies Confidential

2.5 Network Controller Sideband Interface (NC-SI)

The adapter supports a slave Network Controller Sideband Interface (NC-SI) that can be connected to a BMC. The adapter's NC-SI implementation supports all mandatory NC-SI commands specified in the Network Controller Sideband Interface (NC-SI) Specification, Rev. 1.0.0a.

When the ConnectX-3 Pro network controller drive is running (on the main CPU) messages that target the adapter's NC-SI are forwarded by the adapter to the host memory, the adapter then fetches the message from the host memory and forwards it to the BMC over the NC-SI interface.

When the main CPU is powered-down or the adapter network controller is not running, messages that target the adapter's NC-SI are forwarded directly by the adapter to the BMC using the NC-SI interface without being copied to the host memory.

See Appendix B.3, “NC-SI Interface Pinout,” on page 48.

Mellanox Technologies Confidential

3 Hardware Installation

3.1 System Requirements

3.1.1 Hardware

This card requires a PCI Express connector as specified in the Open Compute Project Intel Motherboard spec v2.0.

3.1.2 Operating Systems/Distributions

Please refer to Section 1.3, “Operating Systems/Distributions,” on page 11.

3.1.3 Software Stacks

Mellanox OpenFabric software package - MLNX_EN for Linux, WinOF for Windows and ESX 5.1 for VMware. See Chapter 4, “Driver Installation”.

3.2 Safety Precautions

The card is being installed in a system that operates with voltages that can be lethal. Before opening the case of the system, observe the following precautions to avoid injury and prevent damage to system components.

1. Remove any metallic objects from your hands and wrists.
2. Make sure to use only insulated tools.
3. Verify that the system is powered off and is unplugged.
4. It is strongly recommended to use an ESD strap or other antistatic devices.

3.3 Pre-installation Checklist

1. Verify that your system meets the hardware and software requirements stated above.
2. Shut down your system if active.
3. After shutting down the system, turn off power and unplug the cord.
4. Remove the card from its package. Please note that the card must be placed on an antistatic surface.
5. Check the card for visible signs of damage. Do not attempt to install the card if damaged.

3.4 Card Installation Instructions

To be updated in future release.

3.5 Cables and Modules

To obtain the list of supported cables for your NIC, go to www.mellanox.com => Products => Cables and Transceivers.

Mellanox Technologies Confidential

3.6 Identify the Card in Your System

3.6.1 On Windows

Note: Figure 2 is an example using ConnectX-3 Pro device. This figure will be updated in future releases.

1. Open Device Manager on the server. Click start => Run, and then enter “devmgmt.msc”.
2. Expand System Devices and locate your Mellanox ConnectX-3 Pro network interface card.
3. Right click the mouse on your card's row and select properties to display the network interface card properties window.
4. Click the Details tab and select Device Instance Id (Windows 2003)
5. Hardware Ids (Windows 2008/R2) from the Properties pull-down menu.

Figure 2: PCI Device



6. In the Value display box, check the fields VEN and DEV (fields are separated by ‘&’). In the display example above, notice the sub-string “PCI\VEN_15B3&DEV_1003”: VEN is equal to 0x15B3 – this is the Vendor ID of Mellanox Technologies; and DEV is equal to 1003 – this is a valid Mellanox Technologies PCI Device ID.

If the PCI device does not have a Mellanox adapter ID, return to Step 2 to check another device.

The list of Mellanox Technologies PCI Device IDs can be found in the PCI ID repository at http://pci-ids.ucw.cz/read/PC/15b3.

Mellanox Technologies Confidential

3.6.2 On Linux

Get the device location on the PCI bus by running lspci and locating lines with the string “Mellanox Technologies”:

```
> lspci |grep -i Mellanox

27:00.0 Network controller: Mellanox Technologies MT27520 Family [ConnectX-3 Pro]
```


Mellanox Technologies Confidential

4 Driver Installation

4.1 Linux Driver

For Linux, download and install the latest MLNX_EN driver software package available via the Mellanox web site at: http://www.mellanox.com => Products => Software => Ethernet Drivers => ConnectX®-3 EN 10/40GigE Linux Driver => Download. Follow the installation instructions included in the download package (also available from the download page).

4.1.1 Hardware and Software Requirements

Table 5 - Software and Hardware Requirements

Requirements	Description
Platforms	CPU architectures: • x86_64 • x86 • power-pc
Device ID	For the latest list of device IDs, please visit http://pci-ids.ucw.cz/read/PC/15b3.
Operating System	Linux Operating Systems: • RedHat EL5.8 • RedHat EL5.9 • RedHat EL6.2 • RedHat EL6.3 • OEL6.2 + 2.6.32-279.19.1 • OEL6.3 + 2.6.32-279.19.1 • SLES11 SP1 • SLES11 SP2
Software Dependencies	To install the driver software, kernel sources must be installed on the machine. MLNX_EN driver cannot coexist with OFED software on the same machine. Hence when installing MLNX_EN all OFED packages should be removed (done by the mlnx_en install script)

4.1.2 Installing the Driver

Step 1. Download Driver Package

Please download the current driver package from http://www.mellanox.com => Products => Software => Ethernet Driver => Linux Driver => Download.

Step 2. Install Driver

Run the following commands to install the driver:

```
#> tar xzvf mlnx_en-1.5.10.tgz file
#> cd mlnx_en-1.5.10
#> ./install.sh
```

The package consists of several source RPMs. The install script rebuilds the source RPMs and then installs the created binary RPMs. The created kernel module binaries are placed under /lib/

Mellanox Technologies Confidential

modules/<kernel-ver>/updates/kernel/drivers/net/mlx4. mlnx_en installer supports 2 modes of installation.The install scripts selects the mode of driver installation depending of the running OS/kernel version.

1. Kernel Module Packaging (KMP) mode, where the source rpm is rebuilt for each installed flavor of the kernel. This mode is used for RedHat and SUSE distributions.
2. Non KMP installation mode, where the sources are rebuilt with the running kernel. This mode is used for vanilla kernels.

Note: If the Vanilla kernel is installed as rpm, please use the "--disable-kmp" flag when installing the driver.

The kernel module sources are placed under /usr/src/mellanox-mlnx-en-1.5.10/.Run the following commands to recompile the driver:

```
#> cd /usr/src/mellanox-mlnx-en-1.5.10/
#> scripts/mlnx_en_patch.sh
#> make
#> make install
```

The uninstall and performance tuning scripts are installed.

Note: If the driver was installed without kmp support, the sources would be located under /usr/srs/mlnx_en-1.5.10/

4.1.3 Loading the Driver

Step 1. Make sure no previous driver version is currently loaded

Run:

```
#> modprobe -r mlx4_en
```

Step 2. Load the new driver version

Run:

```
#> modprobe mlx4_en
```

The result is a new net-device appearing in 'ifconfig -a' output.

4.1.4 Unloading the Driver

To unload the Ethernet driver run:

```
#> modprobe mlx4_en
```

4.1.5 Uninstalling the Driver

To uninstall the mlnx_en driver run:

```
#> /sbin/mlnx_en_uninstall.sh
```

4.2 Windows Driver

For Windows, download and install the latest Mellanox WinOF VPI for Windows software package available via the Mellanox web site at: http://www.mellanox.com=> Products => Software

Mellanox Technologies Confidential

=> Ethernet Drivers => Windows SW/Driver => Download. Follow the installation instructions included in the download package (also available from the download page).

4.2.1 Hardware and Software Requirements

Table 6 - Software and Hardware Requirements

Requirements	Description
Required Disk Space for Installation	100 MB
Operating Systems	Windows Server 2012 (64 bit only) Windows Server 2008 R2 (64 bit only)
Installer Privileges	The installation requires administrator privileges on the target machine.

4.2.2 Downloading MLNX_WinOF

Follow these steps to download the .exe according to your Operating System.

Step 1. Verify the machine architecture.

1. Open a CMD console (Click start-->Run and enter CMD).

2. Enter the following command:

```
> echo %PROCESSOR_ARCHITECTURE%
```

On an x64 (64-bit) machine, the output will be “AMD64”.

Step 2. Go to the MLNX_WinOF for Windows Web page at http://www.mellanox.com => Products => Software => Ethernet Drivers => Windows SW/Drivers.

Step 3. Download the .exe image according to the architecture of your machine (see step Step 1.). The name of the .exe is in the following format MLNX_VPI_WinOF-<version>_All_<OS>_<arch>.exe.

Installing the incorrect .exe file is prohibited. If you do so, an error message will be displayed.
For example, if you try to install a 64-bit .exe on a 32-bit machine, the wizard will display the following (or a similar) error message:



4.2.3 Extracting Files Without Running Installation

To extract the files without running installation, perform the following steps.

Step 1. Open a CMD console (Click Start-->Run and enter CMD).

Mellanox Technologies Confidential

Step 2. Enter the following command:

```
MLNX_VPI_WinOF-<version>_All_<OS>_<arch>.exe /a
```

Step 3. Click Next to create a server image.


MLNX_VPI - InstallShield Wizard
Welcome to the InstallShield Wizard for MLNX_VPI
The InstallShield(R) Wizard will install MLNX_VPI on your computer. To continue, click Next.
WARNING: This program is protected by copyright law and international treaties.
< Back
Next >
Cancel

Step 4. Click Change and specify the location in which the files are extracted to.


MLNX_VPI - InstallShield Wizard
Network Location
Specify a network location for the server image of the product.
Enter the network location or click Change to browse to a location. Click Install to create a server image of MLNX_VPI at the specified network location or click Cancel to exit the wizard.
Network location:
N:\
Change...
InstallShield
< Back
Install
Cancel

Mellanox Technologies Confidential

Step 5. Click Install to extract this folder, or click Change to install to a different folder.


MLNX_VPI - InstallShield Wizard
Network Location
Specify a network location for the server image of the product.
Enter the network location or click Change to browse to a location. Click Install to create a server image of MLNX_VPI at the specified network location or click Cancel to exit the wizard.
Network location:
F:\
Change...
InstallShield
< Back
Install
Cancel

Step 6. To complete the extraction, click Finish.


MLNX_VPI - InstallShield Wizard
InstallShield Wizard Completed
The InstallShield Wizard has successfully installed MLNX_VPI. Click Finish to exit the wizard.
< Back
Finish
Cancel

4.2.4 Installing MLNX_WinOF

This section provides instructions for two types of installation procedures:

- "Attended Installation"

  An installation procedure that requires frequent user intervention.

- "Unattended Installation"

Mellanox Technologies Confidential

An automated installation procedure that requires no user intervention.

Both Attended and Unattended installations require administrator privileges.

4.2.4.1 Attended Installation

The following is an example of a MLNX_WinOF_win8 x64 installation session.

Step 1. Double click the .exe and follow the GUI instructions to install MLNX_WinOF.

To configure your setup to contain the logs option, please run the following command after opening a CMD console:

```
MLNX_VPI_WinOF-4_40_0_All_win8_x64.exe /v"/l*vx [LogFile]"
```

If you do not want to upgrade your firmware version, run the following command:

```
MLNX_VPI_WinOF-4_40_0_All_win8_x64.exe /v" MT_SKIPFWUPGRD=1"
```

For further help, please run:

```
MLNX_VPI_WinOF-4_40_0_All_win8_x64.exe /v" /h"
```

Step 2. Click Next in the Welcome screen.


MLNX_VPI - InstallShield Wizard
Welcome to the InstallShield Wizard for MLNX_VPI
The InstallShield(R) Wizard will install MLNX_VPI on your computer. To continue, click Next.
WARNING: This program is protected by copyright law and international treaties.
< Back
Next >
Cancel

Mellanox Technologies Confidential

Step 3. Read then accept the license agreement and click Next.


MLNX_VPI - InstallShield Wizard
License Agreement
Please read the following license agreement carefully.
Copyright (c) 2005-2013, Mellanox Technologies All rights reserved.
Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:
Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
I accept the terms in the license agreement
I do not accept the terms in the license agreement
Print
InstallShield
< Back
Next >
Cancel

Step 4. Select the target folder for the installation.



Step 5. The firmware upgrade screen will be displayed in the following cases:

- If the user has an OEM card, in this case the firmware will not be updated.

Mellanox Technologies Confidential

- If the user has a standard Mellanox card, and the firmware version is older than the one specified in WinOF Installation Guide 4.40, the firmware will be updated accordingly. However, if the user has both OEM card and Mellanox card, only Mellanox card will be updated.

MLNX_VPI - InstallShield Wizard
Firmware Upgrade
Upgrade the HCA's firmware version (Recommended).
Upgrading the firmware version will reboot your machine.
Note: One or more of your HCA adapters has an old firmware version. We recommend upgrading to a newer firmware version to enable improved functionality and support driver's capabilities.
InstallShield
< Back
Next >
Cancel

Step 6. Configure your system for maximum performance by checking the maximum performance box.


MLNX_VPI - InstallShield Wizard
Maximum Performance
Check this box to configure your system for maximum performance.
Check this box to configure your system for maximum performance (Recommended)
Note: This step requires you to reboot the machine at the end of the installation process.
InstallShield
< Back
Next >
Cancel

Mellanox Technologies Confidential

This step requires rebooting your machine at the end of the installation.

Step 7. Select a Complete or Custom installation, follow Step a and on, on page 26.


MLNX_VPI - InstallShield Wizard
Setup Type
Choose the setup type that best suits your needs.
Please select a setup type.
Complete
All program features will be installed. (Requires the most disk space.)
Custom
Choose which program features you want installed and where they will be installed. Recommended for advanced users.
InstallShield
< Back
Next >
Cancel

a. Select the desired feature to install:

- OpenSM - installs Windows OpenSM that is required to mange the subnet from a host. OpenSM is part of the driver and installed automatically.
- Performances tools - install the performance tools that are used to measure the InfiniBand performance in user environment.
- Analyze tools - install the tools that can be used either to diagnosed or analyzed the Infini-Band environment.
- SDK - contains the libraries and DLLs for developing InfiniBand application over IBAL.
- Documentation: contains the User Manual and Installation Guide.
- ND FLTR DLLs: contains the files for standalone installation of the mlx4nd provider.

Mellanox Technologies Confidential



b. Click Install to start the installation.


MLNX_VPI - InstallShield Wizard
Ready to Install the Program
The wizard is ready to begin installation.
Click Install to begin the installation.
If you want to review or change any of your installation settings, click Back. Click Cancel to exit the wizard.
InstallShield
< Back
Install
Cancel

Mellanox Technologies Confidential

Step 8. Click Finish to complete the installation.


MLNX_VPI - InstallShield Wizard
InstallShield Wizard Completed
The InstallShield Wizard has successfully installed MLNX_VPI. Click Finish to exit the wizard.
You chose to run performance tuning. The log file can be found at C:\windows\System32\LogFiles\PerformanceTuning.log
Show release notes
< Back
Finish
Cancel

If the firmware upgrade fails, the following message will be displayed.


MLNX_VPI - InstallShield Wizard
InstallShield Wizard Completed
The InstallShield Wizard has successfully installed MLNX_VPI. Click Finish to exit the wizard.
You chose to run performance tuning. The log file can be found at C:\windows\System32\LogFiles\PerformanceTuning.log
Firmware upgrade failed with error: 1003.
Error Description:
We could not find a new version for the chosen device. Please refer to the UM for...
Show release notes
< Back
Finish
Cancel

4.2.4.2 Unattended Installation

The following is an example of a MLNX_WinOF_win8 x64 unattended installation session.

Step 1. Open the CMD console (click Start > Run and enter ‘cmd’)

Step 2. Install the driver. Run:

```
> MLNX_VPI_WinOF-4_40_0_All_win8_x64.exe /S /v"/qn"
```


Mellanox Technologies Confidential

Step 3. [Optional] To configure your setup to contain the logs option, please run the following command:

```
> MLNX_VPI_WinOF-4_40_0_All_win8_x64.exe /S /v"/qn" /v"/l*vx [LogFile]"
```

Step 4. [Optional] If you do not want to upgrade your firmware version, run the following command:

```
> MLNX_VPI_WinOF-4_40_0_All_win8_x64.exe /S /v"/qn" /v" MT_SKIPFWUPGRD=1"
```

For further help, please run:

```
> MLNX_VPI_WinOF-4_40_0_All_win8_x64.exe /v" /h"
```

4.2.5 Upgrading MLNX_WinOF

The MLNX_WinOF driver upgrades automatically MLNX_WinOF Windows 2008R2 driver by uninstalling the previous version and installs the new driver. However, MLNX_WinOF driver upgrade in Windows 2012 driver do not completely uninstall the previous version.

- In Windows 2012 (MLNX_WinOF Rev. 4.2 and above), the network configuration is saved upon driver upgrade.
- In Windows 2008 R2 the existing configuration files are not saved upon driver upgrade.

4.2.6 Installation Results

Upon installation completion, you can verify the successful addition of the network card(s) through the Device Manager. To see the Mellanox network adapter device, and the Ethernet or IPoIB network device (depending on the used card) for each port, display the Device Manager and expand “System devices” or “Network adapters”.

Mellanox Technologies Confidential

.


Device Manager
File Action View Help
Mellanox ConnectX-3 Ethernet Adapter #2
Microsoft Kernel Debug Network Adapter
Other devices
Unknown device
Ports (COM & LPT)
Print queues
Processors
Storage controllers
System devices
ACPI Fixed Feature Button
Composite Bus Enumerator
Direct memory access controller
High precision event timer
Intel(R) 5520/5500/X58 I/O Hub Control Status and RAS Registers - 3423
Intel(R) 5520/5500/X58 I/O Hub GPIO and Scratch Pad Registers - 3422
Intel(R) 5520/5500/X58 I/O Hub PCI Express Root Port 1 - 3408
Intel(R) 5520/5500/X58 I/O Hub PCI Express Root Port 3 - 340A
Intel(R) 5520/5500/X58 I/O Hub PCI Express Root Port 7 - 340E
Intel(R) 5520/5500/X58 I/O Hub System Management Registers - 342E
Intel(R) 5520/5500/X58 I/O Hub to ESI Port - 3406
Intel(R) 82801 PCI Bridge - 244E
Intel(R) ICH10 Family PCI Express Root Port 1 - 3A40
Intel(R) ICH10 Family PCI Express Root Port 5 - 3A48
Intel(R) ICH10R LPC Interface Controller - 3A16
Mellanox ConnectX-3 (MT04099) Network Adapter
Microsoft ACPI-Compliant System
Microsoft Generic IPMI Compliant Device
Microsoft System Management BIOS Driver
Microsoft Virtual Drive Enumerator
Numeric data processor
PCI Express Root Complex

4.2.7 OpenSM Activation

OpenSM is a service required by managed networks in InfiniBand environments, and must be activated in one of the machines running on the subnet, otherwise the interface link will not come up. If the cards are connected to a managed network, there is no need to run OpenSM. Only one OpenSM should run per subnet.

In Ethernet interfaces, running OpenSM is not required.

OpenSM does not run as a service during installation as it requires the GUID parameter to decide on which port to work. Setting OpenSM upon setup results in it working only for the first port and not for the others.

- ***To run OpenSM as a service, assuming the package was installed in the default path, use:***

```
sc create OpenSM1 binPath= "c:\Program Files\Mellanox\MLNX_VPI\IB\Tools\
opensm.exe --service" start=auto"
```

- ***To start the service, run:***

```
sc start opensm
```

For further information, please refer to the “OpenSM - Subnet Manager” chapter in the User Manual.

Mellanox Technologies Confidential

4.2.8 Uninstalling MLNX_WinOF

4.2.8.1 Attended Uninstall

➢ ***To uninstall MLNX_WinOF on a single node, perform one of the following options:***

1. Click Start-> Control Panel-> Programs and Features-> MLNX_VPI-> Uninstall. (NOTE: This requires elevated administrator privileges.)
2. Double click the .exe and follow the instructions of the install wizard.
3. Click Start-> All Programs-> Mellanox Technologies-> MLNX_WinOF-> Uninstall MLNX_WinOF.

4.2.8.2 Unattended Uninstall

➢ ***To uninstall MLNX_WinOF in unattended mode, perform the following:***

Step 1. Open a CMD console.

Step 2. Uninstall the driver. Run:

```
MLNX_VPI_WinOF-4_40_0_All_win8_x64.exe /S /x /v"/qn"
```

4.2.9 Assigning Port IP After Installation

By default, your machine is configured to obtain an automatic IP address via a DHCP server. In some cases, the DHCP server may require the MAC address of the network adapter installed in your machine.

➢ ***To obtain the MAC address:***

Step 1. Open a CMD console

Step 2. Display the MAC address as "Physical Address"

```
ipconfig /all
```

Configuring a static IP is the same for both IPoIB and Ethernet adapters.

➢ ***To assign a static IP address to a network port after installation:***

Step 1. Open the Network Connections window. Locate Local Area Connections with Mellanox devices.



Step 2. Right-click a Mellanox Local Area Connection and left-click Properties.

Step 3. Select Internet Protocol Version 4 (TCP/IPv4) from the scroll list and click Properties.

Step 4. Select the “Use the following IP address:” radio button and enter the desired IP information.


Internet Protocol Version 4 (TCP/IPv4) Properties
General
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.
Obtain an IP address automatically
Use the following IP address:
IP address:
Subnet mask:
Default gateway:
Obtain DNS server address automatically
Use the following DNS server addresses:
Preferred DNS server:
Alternate DNS server:
Validate settings upon exit
Advanced...
OK
Cancel

Step 5. Click OK.

Step 6. Close the Local Area Connection dialog.

Step 7. Verify the IP configuration by running ‘ipconfig’ from a CMD console.

```
> ipconfig
...
Ethernet adapter Local Area Connection 4:

   Connection-specific DNS Suffix  . :
   IP Address. . . . . . . . . . . . : 11.4.12.63
   Subnet Mask . . . . . . . . . . . : 255.255.0.0
   Default Gateway . . . . . . . . . :
...
```

4.3 VMware Driver

For VMware download and install the latest Mellanox OFED Driver for VMware® ESXi Server-software package available via the Mellanox web site at: http://www.mellanox.com => Products => Software => Ethernet Drivers => VMware Drivers => Download. Follow the installation instructions included in the download package (also available from the download page).

Mellanox Technologies Confidential

4.3.1 Installing and Running the VBI Driver on ESXi-5.x

4. Log into the VMware ESXi server machine as root.
5. You can either:
   a. Remove any earlier version of the driver from your VMware ESXi server machine prior to installing the new version. Run:

```
#> esxcli software vib list
#> esxcli software vib remove -n net-mlx4-en
```

   b. Install the mlx4_en driver VIB package. Run:

```
#> esxcli software vib install -v <vib_url>
```

   c. Reboot ESXi server (The driver will be loaded automatically).

   OR

   a. Update the driver. Run:

```
#> esxcli software vib update -v <vib_url>
```

   b. Reboot ESXi server (The driver will be loaded automatically).

» ***To verify that the driver is loaded, run:***

```
#> vmkload_mod -l | grep mlx4_en
```

» ***To query network uplinks installed on your machine, run:***

```
#> esxcli network nic list
```

The number of uplinks claimed by MLX4_EN driver should be displayed.

In Non Multifunction Mode, port 2 is identified as a pseudo device. Therefore devices are not seen by vSphere when added as uplink.

For further information on how to manipulate the uplink, please refer to Section 5.3, “Adding the Device as an uplink to an Existing Vswitch using the CLI,” on page 10 of the VMware User Manual. See Table 2, “Documents List,” on page 8.

4.3.2 Installing and Running the offline_bundle Driver on ESXi-5.x

1. Copy the offline_bundle zip file to ESXi 5.0 machine and extract its contents.
2. You can install the driver in one of the following ways:
   a. Remove any earlier version of the driver from your VMware ESXi server machine prior to installing the new version. Run:

```
#> esxcli software vib list
#> esxcli software vib remove -n net-mlx4-en
```

   b. Install the mlx4_en driver offline_bundle package. Run:

```
#> esxcli software vib install -d
<path>/mlx4_en-mlnx-1.6.1.2-offline_bundle-471530.zip
```

   c. Reboot ESXi server. (The driver will be loaded automatically).

   OR

Mellanox Technologies Confidential

a. Update the driver. Run:

```
#> esxcli software vib update -n net-mlx4-en -d
<path>/mlx4_en-mlnx-1.6.1.2-offline_bundle-471530.zip
```

b. Reboot ESXi server. (The driver will be loaded automatically).

» ***To verify that the driver is loaded, run:***

```
#> vmkload_mod -l | grep mlx4_en
```

» ***To query network uplinks installed on your machine, run:***

```
#> esxcli network nic list
```

The number of uplinks claimed by MLX4_EN driver should be displayed.

In Non Multifunction Mode, port 2 is identified as a pseudo device. Therefore devices are not seen by vSphere when added as uplink.

For further information on how to manipulate the uplink, please refer to Section 5.3, “Adding the Device as an uplink to an Existing Vswitch using the CLI,” on page 10 of the VMware User Manual. See Table 2, “Documents List,” on page 8.

4.3.3 Removing the VIB/offline_bundle Driver

» ***To remove the VIB/offline_bundle driver package from the ESXi server machine, run:***

```
#> esxcli software vib  remove -n net-mlx4-en
```

4.4 FlexBoot

FlexBoot supports remote Boot over Ethernet. This technology is based on the Preboot Execution Environment (PXE) standard specification, and FlexBoot software is based on the open source iPXE project (see www.ipxe.org). For more information go to http://www.mellanox.com => Products => Software => Ethernet Drivers => Download.

Mellanox Technologies Confidential

5 Updating Card Firmware

Each card is shipped with the latest version of qualified firmware at the time of manufacturing. However, Mellanox issues firmware updates occasionally and the most recent firmware can be obtained from: http://www.mellanox.com => Support. Check that the firmware on your card is the latest found on the Mellanox site, if not update to the latest version found on the Mellanox web site.

Firmware can be updated on the stand-alone single card using the **flint** tool of the *Mellanox Firmware Tools (MFT)* package. This package is available for download, along with its user manual, from the Mellanox Firmware Tools page. See http://www.mellanox.com => Software => Firmware Tools.

The following steps describe how to retrieve the PSID (firmware identification) and programmed firmware version of your network interface card. They also describe how to update the card with the latest firmware version available.

1. Retrieve the PSID and firmware version:
   a. Install the MFT package. The package is available at http://www.mellanox.com => Products => Software => Firmware Tools. Make sure to download the package corresponding to your computer's operating system.
   b. Enter: mst start.
   c. Get the Mellanox *mst device name* using the command "mst status". The mst device name will be of the form: /dev/mst/mt4099_pci_cr0.
   d. Get the PSID (firmware identification) and programmed firmware version using the command.

Note: The shown versions and/or parameter values in the example below may not reflect the latest or actual values for this product, and are included here for illustration purposes only.

```
 flint -d /dev/mst/mt4099_pci_cr0 q
 Image type:      ConnectX
 FW Version:      2.30.4260
 Device ID:       4099
 Description:     Node            Port1           Port2
Sys image
 GUIDs:           ffffffffffffffff ffffffffffffffff
ffffffffffffffff ffffffffffffffff
 MACs:                                  0002c9305350
0002c9305351
 VSD:
 PSID:            MT_1080120023
```

1. Compare the programmed firmware version with the latest available.
   a. Go to Mellanox's web site: http://www.mellanox.com/supportdownloader. See Figure 3.
   b. Enter your card PSID to display the latest firmware file. The file name of the binary is composed by combining the firmware name, the firmware release version, and the card part number.

Note: Please contact Mellanox System Support if you cannot find the firmware binary for your card.

Mellanox Technologies Confidential

Figure 3: Support Download Assistant



1. If a newer firmware version exists for your network interface card on the Web, update the firmware as follows:
   a. Download the firmware (image) zip file from the Support Downloader (see Step 2a above).
   b. Unzip the firmware image.
   c. Burn the firmware image. Enter:

```
> flint -d /dev/mst/mt4099_pci_cr0 -i <binary image> burn
```

   a. Reboot the computer.
   b. Enter: mst start.
   c. Verify that the card firmware was updated successfully.

```
> flint -d /dev/mst/mt4099_pci_cr0  q
Image type:      ConnectX
FW Version:     2.9.4100
Device ID:         4099
...
```


Mellanox Technologies Confidential

6 Troubleshooting

6.1 General

GUID of ConnectX-3 Pro Ethernet adapter cards	• Please use the GUID value returned by the fabric/driver utilities (not 0xfffff). See Appendix A.1, "Retrieving Card GUID," on page 45.
Server unable to find the adapter	• Ensure that the adapter is placed correctly • Make sure the adapter slot and the adapter are compatible • Install the adapter in a different PCI Express slot • Use the drivers that came with the adapter or download the latest • Make sure your motherboard has the latest BIOS • Try to reboot the server
The adapter no longer works	• Reseat the adapter in its slot or a different slot, if necessary • Try using another cable • Reinstall the drivers for the network driver files may be damaged or deleted • Reboot the server
Adapters stopped working after installing another adapter	• Try removing and re-installing all adapters • Check that cables are connected properly • Make sure your motherboard has the latest BIOS
Link indicator light is off	• Ensure that adapter driver/s is loaded • Try another port on the switch • Make sure the cable is securely attached • Check your are using the proper cables that do not exceed the recommended lengths • Verify that your switch and adapter port are compatible
Link light is on, but with no communication established	• Check that the latest driver is loaded • Check that both the adapter and its link are set to the same speed and duplex settings

Mellanox Technologies Confidential

6.2 Linux

Environment Information	cat/etc/issue uname –a cat/proc/cupinfo | grep ‘model name’ | uniq ofed_info | head -1 ifconfig –a ethtool <interface> ethtool –i <interface_of_Mellanox_port_num> ibdev2netdev
Card Detection	lspci | grep –i Mellanox
Mellanox Firmware Tool (MFT)	Download and install MFT: http://www.mellanox.com/content/pages.php?pg=management_tools&menu_section=34 Refer to the User Manual for installation instructions. Once installed, run: mst start mst status flint –d <mst_device> q
Ports Information	ibstat lbv_devinfo
Firmware Version Upgrade	To download the latest firmware version refer to http://www.mellanox.com/supportdownloader
Collect Log File	/var/log/messages dmesg > system.log**F**

Mellanox Technologies Confidential

6.3 Windows

Environment Information	From the Windows desktop choose the Start menu and run: msinfo32 To export system information to a text file, choose the Export option from the File menu. Assign a file name and save.
Mellanox Firmware Tool (MFT)	Download and install MFT: http://www.mellanox.com/content/pages.php?pg=management_tools&menu_section=34 Refer to the User Manual for installation instructions. Once installed, open a CMD window and run: cd C:\Program Files\Mellanox\WinMFT mst start mst status flint –d <mst_device> q
Ports Information	vstat
Firmware Version Upgrade	Download the latest firmware version using the PSID/board ID: http://www.mellanox.com/supportdownloader/ flint –d <mst_device> –i <firmware_bin_file> b

Collect log file	• Event log viewer
	• MST device logs:
	  • mst start
	  • mst status
	  • C:\Users\Administrator> flint –d <mst_device> dc > dump_configuration.log
	  • C:\Users\Administrator> mstdump <mst_device> dc > mstdump.log

Mellanox Technologies Confidential

7 Specifications

7.1 MCX345A-BC[P/Q]N Specifications

Table 7 - MCX345A-BC[P/Q]N Specifications Table

Physical	**Size:** 2.68in. x 4.3 in. (68mm x 110mm)
	Connector: QSFP+ 40Gb/s
Protocol Support	**Ethernet:** 40GBASE-CR4 /-SR4; also supports the following when used with a QSA: 10GBASE-CR/-SR; 1000BASE-T/-SR
	Data Rate: 1/10/40Gb/s – Ethernet
	PCI Express Gen3: SERDES @ 8.0GT/s, 8lanes (2.0 and 1.1 compatible)
Power and Environmental	**Voltage:** 5VAUX and 3.3VAUX
	Typ Power: Passive Cables 7.18W
	Max Power: Passive Cables 7.73W
	Max power available through QSFP+ port: 1.5W
	Temperature: Operational: 0°C to 35°C Non-operational: 0°C to 70°C
	Humidity: 90% relative humidity[a]
	Air Flow: 300LFM[b]
Regulatory	**EMC:** Refer to the following link: www.mellanox.com/related-docs/user_manuals/Regulatory_and_Compliance_Guide.pdf
	Safety: IEC/EN 60950-1:2006 ETSI EN 300 019-2-2 IEC 60068-2- 64, 29, 32
	RoHS: RoHS-R6
Cable Support	Please refer to www.mellanox.com => Products => Cables and Transceivers

a. For both operational and non-operational states

b. Air flow is measured ~1” from the Mezz from the cooling air inlet side.

Mellanox Technologies Confidential

7.2 MCX346A-BC[P/Q]N Specifications

Table 8 - MCX346A-BC[P/Q]N Specifications Table

Physical	**Size:** 2.68in. x 4.3 in. (68mm x 110mm)
	Connector: QSFP+ 40Gb/s
Protocol Support	**Ethernet:** 40GBASE-CR4 /-SR4; also supports the following when used with a QSA: 10GBASE-CR/-SR; 1000BASE-T/-SR
	Data Rate: 1/10/40Gb/s – Ethernet
	PCI Express Gen3: SERDES @ 8.0GT/s, 8 lanes (2.0 and 1.1 compatible)
Power and Environmental	**Voltage:** 5VAUX and 3.3VAUX
	Typ Power: Passive Cables 8.68W
	Max Power: Passive Cables 10.66W
	Max power available through QSFP+ port: 1W
	Temperature: Operational: 0°C to 35°C Non-operational: 0°C to 70°C
	Humidity: 90% relative humidity[a]
	Air Flow: 300LFM[b]
Regulatory	**EMC:** Refer to the following link: www.mellanox.com/related-docs/user_manuals/Regulatory_and_Compliance_Guide.pdf
	Safety: IEC/EN 60950-1:2006 ETSI EN 300 019-2-2 IEC 60068-2- 64, 29, 32
	RoHS: RoHS-R6
Cable Support	Please refer to www.mellanox.com => Products => Cables and Transceivers

a. For both operational and non-operational states

b. Air flow is measured ~1” from the Mezz from the cooling air inlet side.

Mellanox Technologies Confidential

7.3 Board Mechanical Drawing and Dimensions

All dimensions are in millimeters.
All the mechanical tolerances are +/- 0.1mm

Note: For single port cards, Port 2 (J4) is not assembled.

Figure 4: Mechanical Drawing of the Network Interface Card



Mellanox Technologies Confidential

7.4 Adapter LED Operation

There are two I/O LEDs per port. See Table 9 for different LED functions.

Table 9 - Physical and Logical Link Indication

Port and LED	Link LED	Function
P0-LED0	Physical link - Green	40G link is present
	Physical link - Yellow	Other link status is present
P0-LED1	Logical Link/ Activity - Green	
P1-LED0	Physical link - Green	40G link is present
	Physical link - Yellow	Other link status is present
P1-LED1	Logical Link/ Activity - Green	

The short bracket has the same port and LED footprints as the tall bracket.

7.5 Regulatory Statements

For regulatory statements for all ConnectX®-3 Pro cards please refer to:
http://www.mellanox.com/related-docs/user_manuals/Regulatory_and_Compliance_Guide.pdf

Mellanox Technologies Confidential

Appendix A: Finding the MAC/GUID and Serial Number on the Card

Each Mellanox card has a label on the print side that shows the card serial number and the card MAC for Ethernet protocol.

Note: The revision indicated on the labels in the following figures do not necessarily represent the latest revision of the card. Card revision changes are communicated via Product Change Notification (PCN) documents that are available via card suppliers.

Figure 5: MCX345A-BCPN Board Label (Example only - see Note)

Figure 6: MCX345A-BCQN Board Label (Example only - see Note)

Mellanox Technologies Confidential

Figure 7: MCX346A-BCPN Board Label (Example only - see Note)



Figure 8: MCX346A-BCQN Board Label (Example only - see Note)



A.1 Retrieving Card GUID

On ConnectX-3 Pro Ethernet NICs, there is a mismatch between the GUID value returned by firmware management tools and that returned by fabric/driver utilities that read the GUID via device

Mellanox Technologies Confidential

firmware (e.g., using ibstat). Mlxburn/flint returns 0xffff as GUID while the utilities return a value derived from the MAC address. For all driver/firmware/software purposes, the latter value should be used. Please see the below example.

```
ibstat
CA 'mlx4_0'
        CA type: MT4103
        Number of ports: 2
        Firmware version: 2.30.5000
        Hardware version: 0
        Node GUID: 0x0002c90300e8eef0
        System image GUID: 0x0002c90300e8eef0
        Port 1:
                State: Down
                Physical state: Disabled
                Rate: 10
                Base lid: 0
                LMC: 0
                SM lid: 0
                Capability mask: 0x00010000
                Port GUID: 0x0000000000000000
                Link layer: Ethernet
        Port 2:
                State: Down
                Physical state: Disabled
                Rate: 10
                Base lid: 0
                LMC: 0
                SM lid: 0
                Capability mask: 0x00010000
                Port GUID: 0x0000000000000000
                Link layer: Ethernet
```

```
flint -d /dev/mst/mt4103_pci_cr0 -qq q

-W- Running quick query - Skipping full image integrity checks.

Image type:      ConnectX
FW Version:      2.30.5000
Device ID:       4103
Description:     Node            Port1           Port2           Sys image
GUIDs:           0002c90300e8eef0 0002c90300e8eef1 0002c90300e8eef2
0002c90300e8eef3
MACs:                                    0002c9e8eef0     0002c9e8eef1
VSD:             n/a
PSID:            MT_1200111023
```


Mellanox Technologies Confidential

Appendix B: Interface Connectors Pinout

B.1 PCI Express x8 Connector Pinout

The cards use a standard PCI Express x8 connector and the PCI Express x8 standard pinout according to the PCI Express 3.0 specification.

Figure 9: PCIe Connector Pinout



Mellanox Technologies Confidential

B.2 I²C-compatible Connector Pinout

A three hole footprint for I2C Harness is provided as the I2C-compatible interface.

Figure 10: Compatible Connector Plug and Pinout



Table 10 - I2C-compatible Connector Pinout

Connector Pin Number	Signal Name
1	GND
2	SCL
3	SDA

B.3 NC-SI Interface Pinout

Figure 11: NC-SI Interface Pinout



Mellanox Technologies Confidential

Appendix C: Safety Warnings

For safety warnings in French see “Avertissements de sécurité d’installation (Warnings in French)” on page 34. For safety warnings in German see “Sicherheitshinweise (Warnings in German)” on page 36. For safety warnings in Spanish see “Advertencias de seguridad para la instalación (Warnings in Spanish)” on page 38.

1. **Installation Instructions**

Read all installation instructions before connecting the equipment to the power source.

2. **Over-temperature**

This equipment should not be operated in an area with an ambient temperature exceeding the maximum recommended: 55°C (131°F).
To guarantee proper air flow, allow at least 8cm (3 inches) of clearance around the ventilation openings.

3. **During Lightning - Electrical Hazard**

During periods of lightning activity, do not work on the equipment or connect or disconnect cables.

4. **Equipment Disposal**

Disposal of this equipment should be in accordance to all national laws and regulations.

5. **Local and National Electrical Codes**

This equipment should be installed in compliance with local and national electrical codes.

6. **Hazardous Radiation Exposure**

Caution – Use of controls or adjustment or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Mellanox Technologies Confidential

CLASS 1 LASER PRODUCT and reference to the most recent laser standards: IEC 60 825-1:1993 + A1:1997 + A2:2001 and EN 60825-1:1994+A1:1996+ A2:2001

Mellanox Technologies Confidential

Appendix D: Avertissements de sécurité d'installation (Warnings in French)

1. Instructions d'installation

Lisez toutes les instructions d'installation avant de brancher le matériel à la source d'alimentation électrique.

2. Température excessive

Ce matériel ne doit pas fonctionner dans une zone avec une température ambiante dépassant le maximum recommandé de 55°C (131°F). Un flux d'air de 200LFM à cette température ambiante maximale est nécessaire. En outre, pour garantir un bon écoulement de l'air, laissez au moins 8 cm (3 pouces) d'espace libre autour des ouvertures de ventilation.

3. Orages – dangers électriques

Pendant un orage, il ne faut pas utiliser le matériel et il ne faut pas brancher ou débrancher les câbles.

4. Installation du matériel

Ce matériel ne doit être installé, remplacé ou entretenu que par du personnel formé et qualifié.

5. Elimination du matériel

L'élimination de ce matériel doit s'effectuer dans le respect de toutes les législations et réglementations nationales en vigueur.

6. Codes électriques locaux et nationaux

Ce matériel doit être installé dans le respect des codes électriques locaux et nationaux.

Mellanox Technologies Confidential

7. Exposition au rayonnement grave

Mise en garde – l'utilisation de commandes ou de réglages ou l'exécution de procédures autres que ce qui est spécifié dans les présentes peut engendrer une exposition au rayonnement grave.

PRODUIT LASER DE CLASSE 1 » et références aux normes laser les plus récentes CEI 60 825-1:1993 + A1:1997 + A2:2001 et NE 60825-1:1994+A1:1996+ A2:2001

Mellanox Technologies Confidential

Appendix E: Sicherheitshinweise (Warnings in German)

1. Installationsanleitungen

Lesen Sie alle Installationsanleitungen, bevor Sie das Gerät an die Stromversorgung anschließen.

2. Übertemperatur

Dieses Gerät sollte nicht in einem Bereich mit einer Umgebungstemperatur über der maximal empfohlenen Temperatur von 55°C (131°F) betrieben werden. Es ist ein Luftstrom von 200 LFM bei maximaler Umgebungstemperatur erforderlich. Außerdem sollten mindestens 8 cm (3 in.) Freiraum um die Belüftungsöffnungen sein, um einen einwandfreien Luftstrom zu gewährleisten.

3. Bei Gewitter - Elektrische Gefahr

Arbeiten Sie während eines Gewitters und Blitzschlag nicht am Gerät, schließen Sie keine Kabel an oder ab.

4. Geräteinstallation

Diese Gerät sollte nur von geschultem und qualifiziertem Personal installiert, ausgetauscht oder gewartet werden.

5. Geräteentsorgung

Die Entsorgung dieses Geräts sollte unter Beachtung aller nationalen Gesetze Bestimmungen erfolgen.

6. Regionale und nationale elektrische Bestimmungen

Dieses Gerät sollte unter Beachtung der regionalen und nationalen elektrischen Bestimmungen installiert werden.

Mellanox Technologies Confidential

7. Strahlenkontak

Achtung – Nutzung von Steuerungen oder Einstellungen oder Ausführung von Prozeduren, die hier nicht spezifiziert sind, kann zu gefährlichem Strahlenkontakt führen..

Klasse 1 Laserprodukt und Referenzen zu den aktuellsten Lasterstandards : ICE 60 825-1:1993 + A1:1997 + A2:2001 und EN 60825-1:1994+A1:1996+ A2:2001

Mellanox Technologies Confidential

Appendix F: Advertencias de seguridad para la instalación (Warnings in Spanish)

1. Instrucciones de instalación

Antes de conectar el equipo a la fuente de alimentación, leer todas las instrucciones de instalación.

2. Sobrecalentamiento

No se debe utilizar el equipo en un área con una temperatura ambiente superior a la máxima recomendada: 55°C(131°F). Además, para garantizar una circulación de aire adecuada, se debe dejar como mínimo un espacio de 8 cm (3 pulgadas) alrededor de las aberturas de ventilación.

3. Cuando hay rayos: peligro de descarga eléctrica

No utilizar el equipo ni conectar o desconectar cables durante períodos de actividad de rayos.

4. Instalación de equipos

La instalación, el reemplazo y el mantenimiento de este equipo estarán a cargo únicamente de personal capacitado y competente.

5. Eliminación de equipos

La eliminación definitiva de este equipo se debe efectuar conforme a todas las leyes y reglamentaciones nacionales.

6. Códigos eléctricos locales y nacionales

Este equipo se debe instalar conforme a los códigos eléctricos locales y nacionales.

Mellanox Technologies Confidential

7. Exposición a niveles de radiación peligrosos

Precaución: el uso de controles o ajustes o la realización de procedimientos distintos de los que aquí se especifican podrían causar exposición a niveles de radiación peligrosos.

PRODUCTO LÁSER DE CLASE 1 y referencia a las normas de láser más recientes: IEC 60825-1:2007/03 y EN 60825-1:2007

Mellanox Technologies Confidential